



To use LiPo Balancers as an unpluggable unit each balancer should be connected individually to each LiPo cell. It is not advisable to use a row of connectors as it is possible for the balancers to be damaged by having an unequal share of the voltage when they are connected (it is highly likely that the pins of four-pin connector would not all connect instantaneously together).