



At a glance: REVLOCK30 Quick Reference Guide



REVLOCK 30 Set-up and operation summary



RPM selector chart

Range 0 (Inhibited)	Range 1 (8k +)	Range 2 (11k +)	Range 3 (14k +)	Range 4 (17k +)
With throttle at Idle Range 0 is displayed like this ■■■■ on LEDs No RPM set	With throttle at Idle Range 1 is displayed like this ■■■■■ on LEDs	With throttle at Idle Range 2 is displayed like this ■■■■■ on LEDs	With throttle at Idle Range 3 is displayed like this ■■■■■ on LEDs	With throttle at Idle Range 4 is displayed like this ■■■■■ on LEDs
Target engine RPM	Target engine RPM	Target engine RPM	Target engine RPM	Target engine RPM
Offset	Offset	Offset	Offset	Offset
8000 8250 8500 8750 9000 9250 9500 9750 10000 10250 10500 10750 11000 11250 11500 11750	8000 8250 8500 8750 9000 9250 9500 9750 10000 10250 10500 10750 11000 11250 11500 11750	11000 11250 11500 11750 12000 12250 12500 12750 13000 13250 13500 13750 14000 14250 14500 14750	14000 14250 14500 14750 15000 15250 15500 15750 16000 16250 16500 16750 17000 17250 17500 17750	17000 17250 17500 17750 18000 18250 18500 18750 19000 19250 19500 19750 20000 20250 20500 20750

Ranges may also be displayed and adjusted with throttle high by pressing SET
Entering basic set-up erases all data, including ranges